


PARTS CATALOGUE

V125 (5XK1) MALAYSIA



1B5XK-440E1



CONTENTS

ENGINE

CYLINDER	1
CRANKSHAFT & PISTON	2
OIL PUMP	4
INTAKE	5
CARBURETOR	6
EXHAUST	8
CRANKCASE	9
CRANKCASE COVER 1	10
STARTER	11
CLUTCH	12
TRANSMISSION	14
SHIFT CAM & FORK	16
SHIFT SHAFT	17

CHASSIS

FRAME	18
FENDER	19
SIDE COVER	20
OIL TANK	22
REAR ARM & SUSPENSION	23
STEERING	25
FRONT FORK	26
FUEL TANK	27
SEAT	28
FRONT WHEEL FOR SPOKE WHEEL	29
FRONT WHEEL FOR CAST WHEEL	30
FRONT BRAKE CALIPER	31
REAR WHEEL FOR SPOKE WHEEL	32
REAR WHEEL FOR CAST WHEEL	34
REAR BRAKE CALIPER	36
STEERING HANDLE & CABLE	37
FRONT MASTER CYLINDER	39
STAND & FOOTREST	40
REAR MASTER CYLINDER	42
COWLING 1	43
GENERATOR	45
FLASHER LIGHT	46
METER	47
HEADLIGHT	48
TAILLIGHT	49
HANDLE SWITCH & LEVER	50

ELECTRICAL 1	51
ELECTRICAL 2	52

INDEX

NUMERICAL INDEX	53
-----------------------	----




FIG. 1 CYLINDER

[illegible]




FIG. 2 CRANKSHAFT & PISTON

REF. NO.	PART NO.	DESCRIPTION	Z	R		REMARKS
1	5BU-E1400-01	CRANKSHAFT ASSY	1	1		
2	5BU-E1412-01	.CRANK 1	1	1		
3	5BU-E1422-01	.CRANK 2	1	1		
4	34X-11651-00	.ROD, CONNECTING	1	1		
5	55K-11681-00	.PIN, CRANK 1	1	1		
6	90209-22292	.WASHER	2	2		
7	93310-422C8	.BEARING	1	1		
8	5BU-11631-00-A0	PISTON (STD)	1	1		
	5BU-11635-00	PISTON (0.25MM O/S)	1	1		AP
	5BU-11636-00	PISTON (0.50MM O/S)	1	1		AP
9	5BU-11603-00	PISTON RING SET (STD)	1	1		
	5BU-11604-00	PISTON RING SET (0.25MM O/S)	1	1		AP
	5BU-11605-00	PISTON RING SET (0.50MM O/S)	1	1		AP
10	93310-216S7	BEARING	1	1		
11	280-11633-00	PIN, PISTON	1	1		
12	93450-17044	CIRCLIP	2	2		
13	93306-20594	BEARING	2	2		
14	93103-25098	OIL SEAL	1	1		
15	93103-32099	OIL SEAL	1	1		
16	90280-03017	KEY, WOODRUFF	1	1		
17	4XC-11536-01	GEAR, DRIVE	1	1		
18	5BU-E1454-00	WEIGHT 1	1	1		
19	93102-25446	OIL SEAL	1	1		
20	93306-00423	BEARING	1	1		
21	93306-20221	BEARING	1	1		
22	5BU-E1464-00	WEIGHT 2	1	1		
23	4XC-11530-01	BALANCER WEIGHT GEAR COMP.	1	1		





FIG. 2 CRANKSHAFT & PISTON

[illegible]



5BU1440-0040

FIG. 4 INTAKE

REF. NO.	PART NO.	DESCRIPTION	Z	S			REMARKS
1	3BS-13610-00	REED VALVE ASSY	1	1			
2	3BS-13613-00	.REED, VALVE	1	1			
3	10V-13616-01	.STOPPER, REED VALVE	2	2			
4	98507-03008	.SCREW, PAN HEAD	4	4			
5	92907-03100	.WASHER, SPRING	4	4			
6	3BS-13613-10	.REED, VALVE	1	1			
7	5BU-E3621-00	GASKET, VALVE SEAT	1	1			
8	5BU-13565-00	JOINT, CARBURETOR	1	1			
9	90450-44046	HOSE CLAMP ASSY	1	1			
10	95807-06025	BOLT, FLANGE	4	4			
11	90465-08028	CLAMP	1	1			
12	90460-49058	CLAMP, HOSE	1	1			
13	5BU-E4411-00	CASE, AIR CLEANER 1	1	1			
14	5BU-E4412-00	CAP, CLEANER CASE 1	1	1			
15	98507-06025	SCREW, PAN HEAD	3	3			
16	92907-06600	WASHER, PLATE	3	3			
17	5BU-E4451-00	ELEMENT, AIR CLEANER	1	1			
18	5BU-E4476-00	SEAL	1	1			
19	5BU-E4453-00	JOINT, AIR CLEANER 1	1	1			
20	5BU-E4437-00	DUCT	1	1			
21	5BU-E5485-00	CLAMP	1	1			
22	97707-50512	SCREW, TAPPING	1	1			
23	98507-06016	SCREW, PAN HEAD	1	1			
24	92907-06600	WASHER, PLATE	1	1			
25	90159-06033	SCREW, WITH WASHER	1	1			




FIG. 5 CARBURETOR

REF. NO.	PART NO.	DESCRIPTION	N	R				REMARKS
1	5BU-14101-03	CARBURETOR ASSY 1	1	1				
2	537-14186-00	.PIN, FLOAT	1	1				
3	304-14185-00	.FLOAT	1	1				
4	2N4-14145-00	.HOLDER	1	1				
5	12R-14191-00	.PLUG, DRAIN	1	1				
6	304-14184-00	.GASKET, FLOAT CHAMBER	1	1				
7	4AC-14103-00	.THROTTLE SCREW SET	1	1				
8	3XV-14171-00	.PLUNGER, STARTER	1	1				
9	1M1-14169-00	.CAP	1	1				
10	214-14147-00	.O-RING	1	1				
11	5BU-14131-00	.SPRING, THROTTLE VALVE	1	1				
12	4AC-14197-00	.PIPE	1	1				
13	98507-04016	.SCREW, PAN HEAD	4	4				
14	92907-04100	.WASHER, SPRING	4	4				
15	5BU-1490J-00	.NEEDLE SET	1	1				
16	5BU-14126-00	.GASKET	1	1				
17	5BU-14141-32	.NOZZLE, MAIN	1	1				
18	5BU-14112-20	.VALVE, THROTTLE 1	1	1				
19	193-14142-15	.JET, PILOT (# 15)	1	1				
20	3MB-14104-00	.AIR SCREW SET	1	1				
21	21W-14107-20	.NEEDLE VALVE SET	1	1				
22	137-14143-20	.JET, MAIN (#100)	1	1				
23	132-14146-00	.PLATE	1	1				
24	10V-14196-00	.PIPE	1	1				
25	878-14147-00	.O-RING	1	1				
26	509-14135-00	.SPRING, PLUNGER	1	1				
27	3YR-14169-00	.CAP	1	1				




FIG. 6 EXHAUST

REF. NO.	PART NO.	DESCRIPTION	Q	R	REMARKS
1	5XK-E4710-00	MUFFLER ASSY 1	1	1	
2	5BU-E4718-00	.PROTECTOR, MUFFLER 1	1	1	
3	90202-05187	.WASHER, PLATE	8	8	
4	98980-06008	.SCREW, BIND	2	2	
5	5XK-E4758-00	.PROTECTOR, SILENCER	1	1	
6	98907-06008	.SCREW, BIND	2	2	
7	5BU-E4728-00	.PROTECTOR, MUFFLER 2	1	1	
8	5BU-E4738-00	.PROTECTOR, MUFFLER 3	1	1	
9	3NA-14613-01	GASKET, EXHAUST PIPE	1	1	
10	95707-08500	NUT, FLANGE	2	2	
11	97007-08020	BOLT	1	1	
12	92907-08200	WASHER	1	1	
13	95707-08500	NUT, FLANGE	1	1	
14	90201-083A8	WASHER, PLATE	1	1	




FIG. 7 CRANKCASE

REF. NO.	PART NO.	DESCRIPTION	Z	ZR		REMARKS
1	5BU-E5111-00	CRANKCASE 1	1	1		
2	5BU-E5121-00	CRANKCASE 2	1	1		
3	5BU-E5316-00	DAMPER, ENGINE MOUNT 1	4	4		
4	99530-10114	PIN, DOWEL	2	2		
5	90116-08388	BOLT, STUD	2	2		
6	90116-08318	BOLT, STUD	2	2		
7	98507-06035	SCREW, PAN HEAD	3	3		
8	98507-06060	SCREW, PAN HEAD	5	5		
9	98507-06070	SCREW, PAN HEAD	6	6		
10	5BU-E5492-00	COVER	1	1		
11	98507-06012	SCREW, PAN HEAD	2	2		
12	5BU-E5113-00	PLATE	1	1		
13	98507-08010	SCREW, PAN HEAD	1	1		
14	5BU-E3115-00	CONNECTOR, SUCTION PIPE	1	1		
15	90445-08808	HOSE	1	1		
16	5BU-E5484-00	CLAMP 2	1	1		




FIG. 8 CRANKCASE COVER 1

REF. NO.	PART NO.	DESCRIPTION	Z	R			REMARKS
1	5XK-E5411-00	COVER, CRANKCASE 1	1	1			
2	5BU-E5379-00	SEAL, CRANKCASE	1	1			
3	90157-06096	SCREW, PAN HEAD	1	1			
4	90480-09481	GROMMET	1	1			
5	5XK-E5421-00	COVER, CRANKCASE 2	1	1			
6	95807-06016	BOLT, FLANGE	1	1			
7	90430-06166	GASKET	1	1			
8	99530-10114	PIN, DOWEL	2	2			
9	5BU-E5461-00	GASKET, CRANKCASE COVER 2	1	1			
10	3Y1-15363-00	PLUG, OIL	1	1			
11	93210-19123	O-RING	1	1			
12	98507-06030	SCREW, PAN HEAD	5	5			
13	98507-06040	SCREW, PAN HEAD	4	4			
14	95807-08080	BOLT, FLANGE	1	1			
15	90430-08119	GASKET	1	1			
16	5BU-E5441-00	HOLDER, CLUTCH CABLE	1	1			
17	98507-06014	SCREW, PAN HEAD	1	1			
18	5XK-E5416-00	COVER, OIL PUMP	1	1			
19	98507-06020	SCREW, PAN HEAD	2	2			
20	5BU-E3174-00	HOLDER, OIL PIPE	1	1			




FIG. 9 STARTER

[illegible]




FIG. 10 CLUTCH

REF. NO.	PART NO.	DESCRIPTION	N	R				REMARKS
1	5BU-E6150-00	PRIMARY DRIVEN GEAR COMP.	1	1				
2	90201-172U8	WASHER, PLATE	1	1				
3	5BU-E6371-00	BOSS, CLUTCH	1	1				
4	5BU-16321-10	PLATE, FRICTION	4	4				
5	5BU-16324-00	PLATE, CLUTCH 1	4	4				
6	5BU-16331-00	PLATE, FRICTION 2	1	1				
7	5BU-16383-00	SPRING, CLUTCH BOSS	1	1				
8	5BU-E6384-00	PLATE, SEAT	1	1				
9	5BU-E6351-00	PLATE, PRESSURE 1	1	1				
10	5BU-E6352-00	PLATE, PRESSURE 2	1	1				
11	90501-254L6	SPRING, COMPRESSION	4	4				
12	90101-06288	BOLT	4	4				
13	5BU-E6116-00	COLLAR 1	1	1				
14	90201-172U8	WASHER, PLATE	1	1				
15	90208-12015	WASHER, CONICAL SPRING	1	1				
16	90179-12659	NUT	1	1				
17	4TT-16356-00	ROD, PUSH 1	1	1				
18	93306-00106	BEARING	1	1				
19	90201-12163	WASHER, PLATE	1	1				
20	93102-12224	OIL SEAL	1	1				
21	93315-10838	BEARING	1	1				
22	90508-14709	SPRING, TORSION	1	1				
23	5BU-E6380-10	PUSH LEVER ASSY	1	1				
24	2JK-16111-01	GEAR, PRIMARY DRIVE (22T)	1	1				
25	93210-18023	O-RING	1	1				
26	90387-208J9	COLLAR	1	1				
27	90201-120E8	WASHER, PLATE	1	1				




FIG. 10 CLUTCH

[illegible]





FIG. 11 TRANSMISSION


REF. NO.	PART NO.	DESCRIPTION	Z	R			REMARKS
1	5BU-17411-00	AXLE, MAIN (12T)	1	1			
2	10W-17151-02	GEAR, 5TH PINION (23T)	1	1			
3	90201-20266	WASHER, PLATE (T=1.0)	1	1			
4	93410-20038	CIRCLIP	1	1			
5	10W-17131-01	GEAR, 3RD/4TH PINION (19T/21T)	1	1			
6	55K-17121-00	GEAR, 2ND PINION (16T)	1	1			
7	3SB-17161-00	GEAR, 6TH PINION (24T)	1	1			
8	93306-30304	BEARING (B6303Z)	1	1			
9	93306-20201	BEARING (B6202)	1	1			
10	5BU-17421-00	AXLE, DRIVE	1	1			
11	10W-17211-00	GEAR, 1ST WHEEL (34T)	1	1			
12	10W-17251-01	GEAR, 5TH WHEEL (23T)	1	1			
13	10W-17231-00	GEAR, 3RD WHEEL (26T)	1	1			
14	3SB-17241-00	GEAR, 4TH WHEEL (24T)	1	1			
15	10W-17221-00	GEAR, 2ND WHEEL (29T)	1	1			
16	5BU-17261-00	GEAR, 6TH WHEEL (21T)	1	1			
17	90209-18135	WASHER	2	2			
18	93410-22039	CIRCLIP	4	4			
19	90201-22555	WASHER, PLATE	1	1			
20	90201-15700	WASHER, PLATE	1	1			
21	99009-15400	CIRCLIP	1	1			
22	93306-20201	BEARING (B6202)	1	1			
23	93306-30401	BEARING (B6304)	1	1			
24	93102-20143	OIL SEAL	1	1			
25	93822-15070	SPROCKET, DRIVE 15T (5H01746150)	1	1			
26	5BU-E7456-00	HOLDER, SPROCKET	1	1			
27	97027-06010	BOLT	2	2			




 5BU1440-8120

FIG. 12 SHIFT CAM & FORK

REF. NO.	PART NO.	DESCRIPTION	Z	R			REMARKS
1	5BU-18540-00	SHIFT CAM ASSY	1	1			
2	90501-06022	SPRING, COMPRESSION	1	1			
3	4BA-18542-00	POINT, NEUTRAL	1	1			
4	5BU-E8140-00	STOPPER LEVER ASSY	1	1			
5	5BU-18144-10	HANGER, SPRING	1	1			
6	90109-063F8	BOLT	1	1			
7	5BU-18511-00	FORK, SHIFT 1	1	1			
8	5BU-18512-00	FORK, SHIFT 2	1	1			
9	5BU-18513-00	FORK, SHIFT 3	1	1			
10	55K-18531-00	BAR, SHIFT FORK GUIDE 1	1	1			
11	5BU-18535-00	BAR, SHIFT FORK GUIDE 2	1	1			



5BU1440-8140

FIG. 14 FRAME

REF. NO.	PART NO.	DESCRIPTION	N	R			REMARKS
1	5XK-F1110-00-35	FRAME COMP.	1	1			SL
2	90105-10051	BOLT, FLANGE	1	1			
3	95617-10100	NUT, U	1	1			
4	90201-101J1	WASHER, PLATE	1	1			
5	90105-08099	BOLT, FLANGE	2	2			
6	90201-08804	WASHER, PLATE	2	2			
7	95617-08100	NUT, U	2	2			
8	5BU-F1415-00	BRACKET, FRONT UPPER 1	1	1			
9	95807-06014	BOLT, FLANGE	2	2			




FIG. 15 FENDER

REF. NO.	PART NO.	DESCRIPTION	Z	ZR		REMARKS
1	5BU-F1511-00-P0	FENDER, FRONT	1	1		UR VRC1
	5BU-F1511-00-P3	FENDER, FRONT	1			UR DPBMC
2	90480-12314	GROMMET	3	3		
3	90387-068J7	COLLAR	3	3		
4	97027-06020	BOLT	3	3		
5	92907-06600	WASHER, PLATE	3	3		
6	5BU-F1552-00	FENDER, INNER	1	1		
7	90159-06078	SCREW, WITH WASHER	2	2		
8	5BU-F1611-01	FENDER, REAR	1	1		
9	90119-06044	BOLT, WITH WASHER	5	5		
10	90480-01558	GROMMET	1	1		
11	4VH-H5130-00	REAR REFLECTOR ASSY	1	1		
12	95707-05500	NUT, FLANGE	1	1		
13	5BU-F8100-00	TOOL KIT	1	1		




FIG. 16 SIDE COVER

REF. NO.	PART NO.	DESCRIPTION	QTY	QTY	QTY	QTY	REMARKS
1	5BU-F1731-00-P3	COVER, SIDE 3	1	1			BWC1
2	90159-06067	SCREW, WITH WASHER	2	2			
3	90183-05805	NUT, SPRING	1	1			
4	97707-50014	SCREW, TAPPING	2	2			
5	5BU-F1741-00-P3	COVER, SIDE 4	1	1			BWC1
6	90159-06067	SCREW, WITH WASHER	2	2			
7	90183-05805	NUT, SPRING	1	1			
8	97707-50014	SCREW, TAPPING	1	1			
9	5BU-F171E-00-P3	COVER, SIDE 5	1	1			BWC1
10	90159-06067	SCREW, WITH WASHER	2	2			
11	5BU-F177G-00	BOX, BATTERY	1	1			
12	5BU-F124E-00	COVER, BATTERY	1	1			
13	90159-06033	SCREW, WITH WASHER	2	2			
14	90183-06023	NUT, SPRING	2	2			
15	90480-10334	GROMMET	2	2			
16	5BU-F1747-00	DAMPER	1	1			
17	5XK-F173E-00	GRAPHIC 1	1				UR FOR VRC1
	5XK-F173E-10	GRAPHIC 1	1				UR FOR DPBM
	5XK-F173E-20	GRAPHIC 1		1			
18	5XK-F1781-00	EMBLEM 1	1	1			UR FOR VRC1
	5XK-F1781-10	EMBLEM 1	1				UR FOR DPBM
19	5XK-F1781-00	EMBLEM 1	1	1			UR FOR VRC1
	5XK-F1781-10	EMBLEM 1	1				UR FOR DPBM
20	5XK-F1782-00	EMBLEM 2	1	1			
21	5XK-F1782-00	EMBLEM 2	1	1			
22	5XK-F173F-00	GRAPHIC 2	1				UR FOR VRC1
	5XK-F173F-10	GRAPHIC 2	1				UR FOR DPBM




FIG. 16 SIDE COVER

[illegible]




FIG. 17 OIL TANK

[illegible]





FIG. 18 REAR ARM & SUSPENSION

REF. NO.	PART NO.	DESCRIPTION	N	E	REMARKS
1	5BU-F2110-00-WN	REAR ARM COMP.	1	1	CIS
2	93317-218Y4	BEARING	2	2	
3	5BU-F2184-00	BUSH	1	1	
4	55K-22129-00	COVER, THRUST 2	2	2	
5	5BU-F2151-00	SEAL, GUARD	1	1	
6	90119-06044	BOLT, WITH WASHER	1	1	
7	90387-06681	COLLAR	1	1	
8	3AY-F2141-01	SHAFT, PIVOT	1	1	
9	95614-12100	NUT, U	1	1	
10	90201-12688	WASHER, PLATE	1	1	
11	5BU-F2311-00	CASE, CHAIN	1	1	
12	90119-06117	BOLT, WITH WASHER	2	2	
13	5BU-F5887-00	HOLDER, BRAKE HOSE	1	1	
14	95807-06012	BOLT, FLANGE	1	1	
15	5BU-F1650-00	REAR FENDER COMP.	1	1	
16	90267-32192	RIVET, BLIND	1	1	
17	92907-03200	WASHER	1	1	
18	90119-06117	BOLT, WITH WASHER	2	2	
19	5BU-F2143-00	NUT	1	1	
20	5BU-F5876-00	HOLDER, BRAKE HOSE 2	1	1	
21	95807-06012	BOLT, FLANGE	2	2	
22	5BU-F5887-00	HOLDER, BRAKE HOSE	1	1	
23	95807-06012	BOLT, FLANGE	1	1	
24	5BU-F2210-04	SHOCK ABSORBER ASSY, REAR	1	1	
25	90101-12570	BOLT	1	1	
26	90105-12660	BOLT, FLANGE	1	1	
27	90201-12688	WASHER, PLATE	2	2	



5XK1440-B190

FIG. 19 STEERING

REF. NO.	PART NO.	DESCRIPTION	Z	R			REMARKS
1	156-23412-00	RACE, BALL 2	1	1			
2	156-2341E-00	RETAINER, BALL BEARING	1	1			
3	22F-23412-01	RACE, BALL 2	1	1			
4	22F-23411-01	RACE, BALL 1	1	1			
5	22F-2341E-00	RETAINER, BALL BEARING	1	1			
6	3VP-23416-00	COVER, BALL RACE 2	1	1			
7	90179-25802	NUT	2	2			
8	4UV-F3415-00	COVER, BALL RACE 1	1	1			
9	5BU-F3122-00-P0	COVER, OUTER 1	1	1			UR VRC1
	5BU-F3122-00-P3	COVER, OUTER 1	1				UR DPBMC
10	5BU-F3132-00-P0	COVER, OUTER 2	1	1			UR VRC1
	5BU-F3132-00-P3	COVER, OUTER 2	1				UR DPBMC
11	98507-06016	SCREW, PAN HEAD	2	2			
12	90387-06681	COLLAR	2	2			
13	5BU-F5886-00	HOLDER, BRAKE HOSE	1	1			
14	5BU-F3317-00	HOLDER, CABLE	1	1			





FIG. 20 FRONT FORK

REF. NO.	PART NO.	DESCRIPTION	N	R				REMARK
1	5BU-F3100-03	FRONT FORK ASSY	1	1				
2	5BU-F3126-00	.TUBE, OUTER (LEFT)	1	1				
3	5BU-F3136-00	.TUBE, OUTER (RIGHT)	1	1				
4	5BU-F3110-01	.INNER TUBE COMP.1	2	2				
5	5BU-F3170-01	.CYLINDER COMP., FRONT FORK	2	2				
6	5BU-F3152-00	.SPRING, SUB	2	2				
7	5BU-F3157-00	.RING, PISTON	2	2				
8	2JG-F3147-00	.O-RING	2	2				
9	5BU-F3144-00	.SEAL, DUST	2	2				
10	5BU-F3340-00	.UNDER BRACKET COMP.	1	1				
11	5BU-F3141-02	.SPRING, FRONT FORK	2	2				
12	509-F3158-L0	.GASKET	2	2				
13	5LL-F3111-00	.BOLT, CAP	2	2				
14	5LL-F3346-00	.BOLT 1	2	2				
15	278-F3181-50	.BOLT, HEXAGON SOCKET HEAD	2	2				
16	156-23411-00	.RACE, BALL 1	1	1				
17	5BU-F3145-00	.OIL SEAL	2	2				
18	2M6-F3156-00	.CLIP, OIL SEAL	2	2				
19	3YR-F331E-01	GUIDE, CABLE	1	1				
20	95027-06025	BOLT, FLANGE	1	1				



8KK1440-B210

FIG. 21 FUEL TANK

REF. NO.	PART NO.	DESCRIPTION	Q	Q	REMARKS
1	5XK-F4110-00	FUEL TANK COMP.	1	1	
2	97007-06020	BOLT	4	4	
3	90480-18476	GROMMET	4	4	
4	90387-07674	COLLAR	4	4	
5	90201-064K6	WASHER, PLATE	4	4	
6	5BU-F4312-00	PIPE 2	1	1	
7	90467-10008	CLIP	2	2	
8	5BU-F416A-00	HOSE	1	1	
9	4TT-F4500-00	FUEL COCK ASSY 1	1	1	
10	90149-06011	SCREW	2	2	
11	90202-05193	WASHER, PLATE	2	2	
12	5LW-F4610-00	CAP ASSY	1	1	
13	5LW-F4612-00	GASKET, CAP	1	1	
14	5XK-F4198-00	SEAT, RUBBER	1	1	





FIG. 22 SEAT


REF. NO.	PART NO.	DESCRIPTION	N	R				REMARKS
1	5XK-F4730-00	DOUBLE SEAT ASSY	1	1				
2	5XK-F470F-00	.SEAT COVER COMP.	1	1				
3	5BU-F4728-00	.BRACKET, SEAT	1	1				
4	95707-06500	.NUT, FLANGE	1	1				
5	2JG-F4741-00	.PAD, SEAT	6	6				
6	5BU-F4726-00	HINGE, SEAT	1	1				
7	95707-06500	NUT, FLANGE	2	2				
8	90109-065E0	BOLT	1	1				
9	95607-06100	NUT, U	1	1				
10	3YJ-W2470-01	SEAT LOCK ASSY	1	1				
11	2JG-F4796-00	COVER	1	1				
12	98507-06016	SCREW, PAN HEAD	1	1				
13	95607-06100	NUT, U	1	1				
14	5BU-F4780-00	SEAT LOCK ASSY	1	1				
15	95807-06012	BOLT, FLANGE	2	2				
16	5XK-F4773-00-P0	HANDLE, SEAT	1	1				UR VRC1
	5XK-F4773-00-P1	HANDLE, SEAT	1					UR BWC1 FOR U
17	5XK-F4742-00	GROMMET	1	1				
18	91317-08035	BOLT	2	2				
19	341-23469-00	CAP, BOLT	2	2				
20	5BU-F1398-00	HANGER, HELMET	1	1				
21	5XK-H336T-00	HOLDER 1	1	1				
22	98507-04006	SCREW, PAN HEAD	1	1				




 SBU1440-8230

FIG. 23 FRONT WHEEL FOR SPOKE WHEEL

REF. NO.	PART NO.	DESCRIPTION	Q	Q	Q	Q	REMARKS
1	5BU-F5111-00	HUB, FRONT	1				
2	90560-10292	SPACER	1				
3	93106-20816	OIL SEAL	1				
4	93306-30003	BEARING (B6300Z)	2				UR
	93306-300Y9	BEARING	2				UR
5	5BU-F5104-00	SPOKE SET, FRONT	1				
6	94107-178X0	TIRE	1				UR
	94107-17813	TIRE	1				UR
7	94222-17269	TUBE (2.25/2.50-17 TR4)	1				UR INOUE
	94207-17803	TUBE	1				UR
8	94322-17858	BAND, RIM (1.20-17)	1				UR INOUE
	94307-17803	BAND, RIM	1				UR
9	94414-17888	RIM (1.40-17)	1				UR
	94414-178C6	RIM (1.40-17)	1				UR
10	5BU-F5398-00	BALANCER, WHEEL	1				UN
11	90387-10277	COLLAR	1				
12	4UV-F5181-00	AXLE, WHEEL	1				
13	90185-10091	NUT, SELF-LOCKING	1				
14	90201-101J1	WASHER, PLATE	1				
15	5BU-F5190-00	GEAR UNIT ASSY	1				



FWD
5NM1431-1230

FIG. 24 FRONT WHEEL FOR CAST WHEEL

REF. NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	5NM-F5168-00-UA	CAST WHEEL, FRONT	1	CWW
2	90560-10292	SPACER	1	
3	93106-20816	OIL SEAL	1	
4	93306-30003	BEARING (B6300Z)	2	UR
	93306-300Y9	BEARING	2	UR
5	94107-178X0	TIRE	1	
6	94222-17269	TUBE (2.25/2.50-17 TR4)	1	INOUE
7	1A1-25398-01	BALANCER, WHEEL (20G)	1	UN
	1A1-25399-00	BALANCER, WHEEL (10G)	1	UN
	2M0-25399-00	BALANCER, WHEEL (30G)	1	UN
8	90387-10277	COLLAR	1	
9	4UV-F5181-00	AXLE, WHEEL	1	
10	90185-10091	NUT, SELF-LOCKING	1	
11	90201-101J1	WASHER, PLATE	1	
12	5BU-F5190-00	GEAR UNIT ASSY	1	




FIG. 25 FRONT BRAKE CALIPER

REF. NO.	PART NO.	DESCRIPTION	N	R			REMARKS
1	4VH-F582U-00	DISC, BRAKE (RIGHT)	1	1			
2	90109-08718	BOLT	4	4			
3	5NM-F580U-00	CALIPER ASSY (RIGHT)	1	1			
4	5BU-W0057-50	.PISTON ASSY, CALIPER	1	1			
5	3LC-W0047-50	..CALIPER SEAL KIT	1	1			
6	5NM-F5811-00	.PAD, CALIPER 2	1	1			
7	5NM-F5811-10	.PAD, CALIPER 2	1	1			
8	1UY-W0048-50	.BLEED SCREW KIT	1	1			
9	3LD-25934-01	.SPRING, PAD	1	1			
10	3LD-25924-00	.PIN, PAD	2	2			
11	3SP-25926-51	.BOLT	1	1			
12	1UY-25937-51	.BOOT 2	1	1			
13	90105-10638	BOLT, FLANGE	2	2			




FIG. 26 REAR WHEEL FOR SPOKE WHEEL

REF. NO.	PART NO.	DESCRIPTION	QTY	REMARK
1	5BU-F5311-00	HUB, REAR	1	
2	90387-128V7	COLLAR	1	
3	93306-30103	BEARING (B6301Z)	1	UR
	93306-301X3	BEARING	1	UR
4	93306-30101	BEARING (B6301)	1	
5	93210-41041	O-RING	1	
6	5H3-F5364-00	DAMPER	4	
7	93106-20033	OIL SEAL	1	
8	5BU-F5366-00	CLUTCH, HUB	1	
9	93106-30817	OIL SEAL	1	
10	90387-127Y0	COLLAR	1	
11	93306-00406	BEARING (B6004Z)	1	UR NTN
	93306-004YD	BEARING	1	UR
12	5BU-F5443-10	SPROCKET, DRIVEN (43T)	1	
13	90116-08218	BOLT, STUD	4	
14	4AW-25412-00	WASHER	2	
15	90170-08258	NUT	4	
16	3YR-F5304-00	SPOKE SET, REAR	1	
17	94108-178X1	TIRE	1	UR
	94108-17812	TIRE	1	UR
18	94227-17106	TUBE (2.75/3.0-17 TR4)	1	UR INOUE
	94208-17802	TUBE	1	UR
19	94322-17858	BAND, RIM (1.20-17)	1	UR INOUE
	94307-17803	BAND, RIM	1	UR
20	94416-17893	RIM (1.60-17)	1	UR
	94416-178C5	RIM (1.60-17)	1	UR
21	5BU-F5398-00	BALANCER, WHEEL	1	UN




FIG. 26 REAR WHEEL FOR SPOKE WHEEL

REF. NO.	PART NO.	DESCRIPTION	QTY	REMARKS
22	2R6-22141-00	SHAFT, PIVOT	1	
23	90201-120T5	WASHER, PLATE	2	
24	90185-12046	NUT, SELF-LOCKING	1	
25	90387-128H8	COLLAR	1	
26	90387-123N2	COLLAR	1	
27	5BU-F5388-00	PULLER, CHAIN 1	2	
28	5BU-F2174-00	END 1	2	
29	95307-08600	NUT	4	
30	92907-08600	WASHER, PLATE	2	
31	94508-30120	CHAIN	1	
32	94608-30001	JOINT, CHAIN	1	




FIG. 27 REAR WHEEL FOR CAST WHEEL

REF. NO.	PART NO.	DESCRIPTION	Z	R			REMAI
1	5NM-F5338-00-UA	CAST WHEEL, REAR		1			CWW
2	90387-123A9	COLLAR		1			
3	93306-30103	BEARING (B6301Z)		1			UR
	93306-301X3	BEARING		1			UR
4	93306-30101	BEARING (B6301)		1			
5	93210-41041	O-RING		1			
6	5H3-F5364-00	DAMPER		4			
7	93106-20033	OIL SEAL		1			
8	3SB-F5366-00	CLUTCH, HUB		1			
9	93106-30817	OIL SEAL		1			
10	90387-128A5	COLLAR		1			
11	93306-00406	BEARING (B6004Z)		1			UR NTN
	93306-004YD	BEARING		1			UR
12	5BU-F5443-10	SPROCKET, DRIVEN (43T)		1			
13	90109-08864	BOLT		4			
14	4TT-F5412-00	WASHER		2			
15	90179-08888	NUT		4			
16	94108-178X1	TIRE		1			UR
	94108-17812	TIRE		1			UR
17	94227-17106	TUBE (2.75/3.0-17 TR4)		1			UR INQUE
	94208-17802	TUBE		1			UR
18	1A1-25398-01	BALANCER, WHEEL (20G)		1			UN
	1A1-25399-00	BALANCER, WHEEL (10G)		1			UN
	2M0-25399-00	BALANCER, WHEEL (30G)		1			UN
19	2R6-22141-00	SHAFT, PIVOT		1			
20	90201-120T5	WASHER, PLATE		2			
21	90185-12046	NUT, SELF-LOCKING		1			





FIG. 28 REAR BRAKE CALIPER

REF. NO.	PART NO.	DESCRIPTION	Z	R			REMARK
1	5BU-F582W-00	DISC, REAR BRAKE 2	1	1			
2	90149-08268	SCREW	4	4			
3	5BU-2580W-00	CALIPER ASSY, REAR 2	1	1			
4	5BU-W0057-50	.PISTON ASSY, CALIPER	1	1			
5	3LC-W0047-50	..CALIPER SEAL KIT	1	1			
6	5BU-W0046-00	.BRAKE PAD KIT 2	1	1			
7	1UY-W0048-50	.BLEED SCREW KIT	1	1			
8	3LD-25934-01	.SPRING, PAD	1	1			
9	3SP-25924-51	.PIN, PAD	2	2			
10	5BU-24834-00	.BOLT	2	2			
11	95827-10030	BOLT, FLANGE	1	1			
12	90201-10140	WASHER, PLATE	1	1			



HXK1440-B290

FIG. 29 STEERING HANDLE & CABLE

REF. NO.	PART NO.	DESCRIPTION	N	R	REMARKS
1	5BU-F6210-00	HANDLE	1	1	
2	90105-10036	BOLT, FLANGE	1	1	
3	90185-10154	NUT, SELF-LOCKING	1	1	
4	5BU-F6246-00	END, GRIP	2	2	
5	5XK-F6143-00-P0	COVER, HANDLEBAR UPPER 1	1	1	UR VRC1
	5XK-F6143-00-P1	COVER, HANDLEBAR UPPER 1	1		UR DPBMC
6	5BU-F6145-00	COVER, HANDLEBAR UPPER 2	1	1	
7	5BU-H4164-00	DAMPER	1	1	
8	97707-50016	SCREW, TAPPING	2	2	
9	97707-50016	SCREW, TAPPING	2	2	
10	90183-05805	NUT, SPRING	2	2	
11	97707-50016	SCREW, TAPPING	2	2	
12	3RY-26199-00	PLUG, BLIND	1	1	
13	5BU-F6240-00	GRIP ASSY	1	1	
14	5BU-F6241-00	GRIP	1	1	
15	5XK-F6280-00	REAR VIEW MIRROR ASSY (LEFT)	1	1	
16	5XK-F6290-00	REAR VIEW MIRROR ASSY (RIGHT)	1	1	
17	5LW-F629T-00	BOOT 1	2	2	
18	5BU-F6260-00	CABLE ASSY, THROTTLE & PUMP	1	1	
19	5H0-26393-00	HOLDER	1	1	
20	90468-08086	CLIP	1	1	
21	5BU-F6331-00	CABLE, STARTER 1	1	1	
22	90464-50801	CLAMP	1	1	
23	5BU-F6335-00	CABLE, CLUTCH	1	1	
24	90123-08046	BOLT	1	1	
25	90170-08401	NUT	1	1	
26	5XK-F8381-00	WINDSHIELD	1	1	




FIG. 29 STEERING HANDLE & CABLE

[illegible]




FIG. 30 FRONT MASTER CYLINDER

REF. NO.	PART NO.	DESCRIPTION	Z	R			REMARKS
1	5XK-F5872-00	HOSE, BRAKE 1	1	1			
2	90401-10159	BOLT, UNION	2	2			
3	90201-10118	WASHER, PLATE	4	4			
4	5LN-F583T-01	MASTER CYLINDER ASSY	1	1			
5	5HV-W0042-50	.CYLINDER KIT, MASTER	1	1			
6	5HV-F5852-00	.CAP, RESERVOIR	1	1			
7	5HV-F585B-00	.PLATE, DIAPHRAGM	1	1			
8	5HV-F5854-00	.DIAPHRAGM, RESERVOIR	1	1			
9	9870M-04012	.SCREW, FLAT HEAD	2	2			
10	5TN-H3922-00	.LEVER 2	1	1			
11	90109-06577	.BOLT	1	1			
12	9560M-06100	.NUT, U	1	1			
13	5LW-H3980-00	.FRONT STOP SWITCH ASSY	1	1			
14	9760L-04212	.SCREW, PAN HEAD WITH WASHER	1	1			
15	56A-F5867-00	.BRACKET, MASTER CYLINDER	1	1			
16	5LW-F6332-00	.BOLT	2	2			




FIG. 31 STAND & FOOTREST

REF. NO.	PART NO.	DESCRIPTION	Z	ZB			REMARK
1	5BU-F7111-00	STAND, MAIN	1	1			
2	5BU-F7214-00	STOPPER	1	1			
3	439-27112-00	SHAFT, MAIN STAND	1	1			
4	93430-12008	CIRCLIP	1	1			
5	90506-35474	SPRING, TENSION	1	1			
6	90445-228B8	HOSE	1	1			
7	5BU-F7211-00	PEDAL, BRAKE	1	1			
8	90201-14411	WASHER, PLATE	1	1			
9	93430-10015	CIRCLIP	1	1			
10	90506-20369	SPRING, TENSION	1	1			
11	5BU-F7311-00	STAND, SIDE	1	1			
12	90109-08034	BOLT	1	1			
13	95307-08700	NUT	1	1			
14	90506-20514	SPRING, TENSION	1	1			
15	90445-21848	HOSE (L70)	1	1			
16	5XK-F7452-00	BRACKET, FOOTREST 1	1	1			
17	5XK-F7422-00	BRACKET, FOOTREST 2	1	1			
18	95827-10020	BOLT, FLANGE	2	2			
19	5AB-F7451-00	FOOTREST	1	1			
20	5AB-F7413-00	COVER, FOOTREST	1	1			
21	90508-20023	SPRING, TORSION	1	1			
22	91317-06012	BOLT	2	2			
23	5AB-F7425-00	BRACKET, FOOTREST 2	1	1			
24	5BU-F7462-00	BRACKET, FOOTREST 2	1	1			
25	92017-08020	BOLT, BUTTON HEAD	2	2			
26	5AB-F7461-00	FOOTREST	1	1			
27	5AB-F7413-00	COVER, FOOTREST	1	1			




FIG. 31 STAND & FOOTREST

REF. NO.	PART NO.	DESCRIPTION	N	Q			REMARKS
28	90508-20631	SPRING, TORSION	1	1			
29	91317-06012	BOLT	2	2			
30	5AB-F7425-00	BRACKET, FOOTREST 2	1	1			
31	90240-08084	PIN, CLEVIS	2	2			
32	91401-25015	PIN, COTTER	2	2			
33	5XK-F7430-00	REAR FOOTREST ASSY 1	1	1			
34	5BU-F7433-00	.COVER, REAR FOOTREST	1	1			
35	95807-08020	BOLT, FLANGE	2	2			
36	5XK-F7440-00	REAR FOOTREST ASSY 2	1	1			
37	5BU-F7444-00	.COVER, REAR FOOTREST	1	1			
38	95807-08020	BOLT, FLANGE	2	2			




FIG. 32 REAR MASTER CYLINDER

REF. NO.	PART NO.	DESCRIPTION	Q	R				REMAF
1	5BU-2583V-00	RR. MASTER CYLINDER ASSY.	1	1				
2	5BU-W0042-50	.CYLINDER KIT, MASTER	1	1				
3	93210-15620	.O-RING	1	1				
4	2VN-25866-00	.CIRCLIP	1	1				
5	4ML-2582A-50	.JOINT	1	1				
6	2YK-27222-00	.JOINT	1	1				
7	95301-08700	.NUT	2	2				
8	4EW-25894-00	.TANK, RESERVOIR	1	1				
9	2VN-25852-00	.CAP, RESERVOIR	1	1				
10	2VN-25855-00	.BUSH, DIAPHRAGM	1	1				
11	2VN-25854-00	.DIAPHRAGM, RESERVOIR	1	1				
12	90467-12085	.CLIP	2	2				
13	5BU-25895-00	.HOSE, RESERVOIR	1	1				
14	3FV-2589A-00	.COVER, DUST	1	1				
15	5BU-27234-00	.PIN, BRAKE ROD	1	1				
16	95827-06020	BOLT, FLANGE	2	2				
17	90159-06056	SCREW, WITH WASHER	1	1				
18	5BU-F5888-00	COVER, RESERVOIR TANK	1	1				
19	90240-08124	PIN, CLEVIS	1	1				
20	90201-08083	WASHER, PLATE	1	1				
21	91401-16012	PIN, COTTER	1	1				
22	5XK-F5873-00	HOSE, BRAKE 2	1	1				
23	90401-10159	BOLT, UNION	2	2				
24	5BU-25844-00	WASHER, LOCK	1	1				
25	90201-10118	WASHER, PLATE	3	3				




FIG. 33 COWLING 1

REF. NO.	PART NO.	DESCRIPTION	QTY	QTY	REMARKS
1	5BU-F8311-00	LEG SHIELD 1	1	1	
2	97707-50010	SCREW, TAPPING	4	4	
3	90183-05805	NUT, SPRING	1	1	
4	5BU-F8312-00	LEG SHIELD 2	1	1	
5	97707-50010	SCREW, TAPPING	4	4	
6	90183-05805	NUT, SPRING	1	1	
7	5BU-F8321-00	STAY 1	1	1	
8	5BU-F8322-00	STAY 2	1	1	
9	97007-06012	BOLT	4	4	
10	92907-06600	WASHER, PLATE	4	4	
11	5BU-F8385-00-P0	COVER, LOWER	1	1	UR VRC1
	5BU-F8385-00-P3	COVER, LOWER	1		UR DPBMC
12	90159-06165	SCREW, WITH WASHER	3	3	
13	90183-05805	NUT, SPRING	6	6	
14	97707-50014	SCREW, TAPPING	1	1	
15	5BU-F8395-00-P0	COVER, UNDER	1	1	UR VRC1
	5BU-F8395-00-P3	COVER, UNDER	1		UR DPBMC
16	90159-06165	SCREW, WITH WASHER	3	3	
17	90183-05805	NUT, SPRING	3	3	
18	97707-50014	SCREW, TAPPING	3	3	
19	5BU-F842M-00	COVER 1	1	1	
20	90159-06165	SCREW, WITH WASHER	1	1	
21	97707-50014	SCREW, TAPPING	1	1	
22	5BU-F842N-00	COVER 2	1	1	
23	90159-06165	SCREW, WITH WASHER	1	1	
24	97707-50010	SCREW, TAPPING	1	1	
25	5BU-F843J-00	COVER 3	1	1	




FIG. 33 COWLING 1

REF. NO.	PART NO.	DESCRIPTION	Z	R			REMARK
26	90159-06165	SCREW, WITH WASHER	1	1			
27	97707-50010	SCREW, TAPPING	1	1			
28	90480-13804	GROMMET	1	1			
29	90183-05805	NUT, SPRING	1	1			
30	99241-00120	EMBLEM, YAMAHA	1				UR FOR VI
	99244-00120	EMBLEM, YAMAHA	1				UR FOR DI
	5XK-F8393-00	GRAPHIC 3		1			
31	99241-00120	EMBLEM, YAMAHA	1				UR FOR VI
	99244-00120	EMBLEM, YAMAHA	1				UR FOR DI
	5XK-F8394-00	GRAPHIC 4		1			
32	5XK-F839H-00	EMBLEM 1	1				UR FOR VF
	5XK-F839H-10	EMBLEM 1	1				UR FOR DF
	5XK-F839H-20	EMBLEM 1		1			
33	5XK-F841J-00	EMBLEM 2	1				UR FOR VR
	5XK-F841J-10	EMBLEM 2	1				UR FOR DP
	5XK-F841J-20	EMBLEM 2		1			
34	5BU-F3391-00-P0	PANEL, FRONT	1	1			UR VRC1
	5BU-F3391-00-P3	PANEL, FRONT	1				UR DPBMC
35	97707-50014	SCREW, TAPPING	3	3			
36	5BU-F836B-00	TUNING FORK MARK	1	1			





FIG. 34 GENERATOR

[illegible]




5XK1440-B350

FIG. 35 FLASHER LIGHT

REF. NO.	PART NO.	DESCRIPTION	Z	ZR				REMARKS
1	5XK-H3310-00	FRONT FLASHER LIGHT ASSY 1	1	1				
2	5LM-H3311-00	.BULB, FLASHER (12V-10W)	1	1				
3	5XK-H3312-00	.LENS, FLASHER	1	1				
4	97702-40616	.SCREW, TAPPING	1	1				
5	5XK-H3320-00	FRONT FLASHER LIGHT ASSY 2	1	1				
6	5LM-H3311-00	.BULB, FLASHER (12V-10W)	1	1				
7	5XK-H3322-00	.LENS, FLASHER 2	1	1				
8	97702-40616	.SCREW, TAPPING	1	1				
9	97707-40012	SCREW, TAPPING	2	2				

[illegible]

5XK1440-B380





FIG. 38 TAILLIGHT

REF. NO.	PART NO.	DESCRIPTION	QTY	QTY	REMARKS
1	5XK-H4710-00	TAILLIGHT UNIT ASSY	1	1	
2	3XA-H4714-00	.BULB (12V 21/5W)	1	1	
3	5LM-H3311-00	.BULB, FLASHER (12V-10W)	2	2	
4	5PV-H3332-00	.LENS, FLASHER	1	1	
5	5CT-8472F-00	.LENS, LICENCE LIGHT	1	1	LM
6	5CT-H4721-00	.LENS, TAILLIGHT	1	1	
7	97706-40620	.SCREW, TAPPING	4	4	
8	5CT-H4728-00	.SHADE 1	1	1	
9	90480-18880	GROMMET	2	2	
10	90387-066M1	COLLAR	2	2	
11	90201-06071	WASHER, PLATE	2	2	
12	95307-06600	NUT	2	2	
13	90480-13428	GROMMET	2	2	
14	90183-05805	NUT, SPRING	3	3	



5XK1440-B390

FIG. 39 HANDLE SWITCH & LEVER

REF. NO.	PART NO.	DESCRIPTION	Z	ZR	REMARKS
1	5BU-H3973-00	SWITCH, HANDLE 3	1	1	
2	5BU-H3929-00	.PLATE, SPRING	1	1	
3	5BU-H3941-00	.LEVER, STARTER	1	1	
4	5BU-H398X-00	.WASHER, PLAIN	1	1	
5	5BU-H3925-00	.SCREW, LEVER FITTING	1	1	
6	98506-05035	.SCREW, PAN HEAD	2	2	
7	5BU-F628J-00	CAP, GRIP	1	1	
8	98507-05040	.SCREW, PAN HEAD	1	1	
9	98507-05045	.SCREW, PAN HEAD	1	1	
10	1NV-83912-00	LEVER 1	1	1	
11	90109-06797	BOLT	1	1	
12	95607-06100	NUT, U	1	1	
13	3YR-82911-00	HOLDER, LEVER 1	1	1	
14	97007-06025	BOLT	1	1	
15	92907-06600	WASHER, PLATE	1	1	




FIG. 40 ELECTRICAL 1

REF. NO.	PART NO.	DESCRIPTION	N	R			REMARKS
1	5BU-85540-01	C.D.I. UNIT ASSY	1	1			
2	5BP-H2310-00	IGNITION COIL ASSY	1	1			
3	90153-06047	SCREW, HEXAGON	2	2			
4	81E-82370-30	PLUG CAP ASSY	1	1			
5	5BU-82540-00	NEUTRAL SWITCH ASSY	1	1			
6	93210-27194	O-RING	1	1			
7	98507-05016	SCREW, PAN HEAD	2	2			
8	92907-05600	WASHER, PLATE	2	2			
9	35R-83350-20	FLASHER RELAY ASSY	1	1			
10	5BU-H3371-00	HORN	1	1			
11	95807-06008	BOLT, FLANGE	1	1			
12	5XK-H5752-00	SENDER UNIT ASSY, FUEL METER	1	1			
13	5LW-H5753-00	GASKET, SENDER UNIT	1	1			
14	90109-05003	BOLT	4	4			
15	92907-08200	WASHER	4	4			
16	5XK-H3720-00	L.E.D ASS'Y	1	1			
17	98907-06016	SCREW, BIND	2	2			
18	90387-061N0	COLLAR	2	2			
19	90480-13805	GROMMET	2	2			




FIG. 41 ELECTRICAL 2

REF. NO.	PART NO.	DESCRIPTION	QTY	QTY	QTY	QTY	REMARKS
1	5BU-H2110-00	BATTERY ASSY	1	1			
2	5BU-H2150-00	FUSE HOLDER ASSY	1	1			
3	4AP-H2151-00	.FUSE (10A)	1	1			
4	5BU-82501-00	MAIN SWITCH STEERING LOCK	1	1			
5	2JG-H2552-00	CAP, SWITCH	1	1			
6	5BU-H2514-00	STAY, MAIN SWITCH	1	1			
7	91317-06014	BOLT	2	2			
8	5BU-82530-00	STOP SWITCH ASSY	1	1			
9	5XK-H2590-00	WIRE HARNESS ASSY	1	1			
10	90464-50801	CLAMP	4	4			
11	3XC-85720-02	OIL LEVEL GAUGE ASSY	1	1			
12	4UL-H1960-00	RECTIFIER & REGULATOR ASSY	1	1			
13	98507-06016	SCREW, PAN HEAD	1	1			
14	92907-06600	WASHER, PLATE	1	1			
15	90445-083F2	HOSE (L620)	1	1			

V125
PARTS CATALOGUE
©2003 by Yamaha Motor Co., Ltd.
1st edition, August 2003
All rights reserved.
Any reprinting or unauthorized use
without the written permission of
Yamaha Motor Co., Ltd.
is expressly prohibited.
Printed in Japan. TM